



Ultrasound Solutions

UAS3

UASLite

Database Migration Guide

Version 1 – 2021

© SDT International. All rights reserved. Specifications are subject to change without notice.


Table of Contents

Table of Contents	2
1. How to migrate Database Server	3
2. Migrate Database Server	5


1. How to migrate Database Server

After upgrading your UAS3 and UASLite to the latest version, launch the software.


UAS3/UASLite will detect that a new Database Server version is available. See picture below.



Click to open the download window.




You should see the following window:




Click **Download** to start download the migration tool.


Wait until the download is completed.



When the download is completed click **Ok** on the next window to exit UAS3/UASLite and start installation of the Migration Tool.




After UAS3/UASLite exit, you will see the window below. Click **Install** to start the installation.



2. Migrate Database Server

When the installation is completed, the Migration Tool will start.




By clicking **Start**, the tool will:

1. Make a full backup of your UAS3.
2. Uninstall the current Database Server (PostgreSQL 8.9.4)
3. Install the new Database Server (PostgreSQL 13.1)
4. Restore the backup, made in step, into the new Database Server.

Step 1: Backup the data.


This step may take a very long time depending on the amount of data. So, wait...




Step 2: Uninstall current Database Server.

When the backup is completed, the uninstallation of the current Database Server will start.

Accept by clicking **Yes**.





Click **Ok** to confirm the uninstallation.







Step 3: Installation of the new Database Server.

Click **Next** at each step.




Leave the default choices and click **Next** for each screen.






The installation starts.



Wait...




Click the **Finish** button to complete PostGreSQL installation.

Step 4: Restore backup.

The restore of the backup made in step 1 will automatically start.

This may take a long time. So be patient.



When the restore is finished, Data Migration Tool will automatically close itself.

You can now start UAS3/UASLite.