Installation de l'application DataDump

Contenu

Installation depuis le CD-Rom Installation en ligne Démarrage de l'installation

Installation à partir du CD-Rom

Lancer le CD-Rom livré avec votre équipement. Après avoir choisi une langue, depuis la page principale sélectionner "*Logiciel DataDump*".



Puis sélectionner "Installer le logiciel".



Continuer l'installation en vous reportant au chapitre "Démarrage de l'installation".

Installation en ligne

Visiter notre site ftp, à l'adresse <u>ftp://ftp.sdt.be/pub/Software/SDT270DataDump</u>. Sélectionner le dossier "*Latest version*" puis double-cliquer sur le fichier "*SDT270DataDump.msi*".

Démarrage de l'installation

Vous devriez maintenant visualiser la fenêtre suivante :



Cliquer sur "Next', l'écran suivant apparaît :

🕫 SDT 270 Data Dump 📃 🗖 🔀		
Select Installation Folder		
The installer will install SDT270 Data Dump to the following folder.		
To install in this folder, click "Next". To install to a different folder, enter it below or click "Browse".		
Eolder: C:\Program Files\SDT\SDT270 Data Dump\ Disk Cost		
Install SDT270 Data Dump for yourself, or for anyone who uses this computer:		
C Everyone		
● Just me		
Cancel < Back Next >		

Par défaut, l'application DataDump sera installée dans le dossier C:\Fichiers programme\SDT270 Data Dump. Toutefois, vous pouvez spécifier un dossier cible de votre choix en appuyant sur le bouton "**Browse**". Cliquer sur le bouton "**Next**". La fenêtre ci-dessous apparaît :

🔞 SDT270 Data Dump	
Confirm Installation	
The installer is ready to install SDT270 Data Dump on your computer. Click "Next" to start the installation.	
Cancel < Back (Next>

Cliquer sur "Next".

Installation de l'application DataDump

🔞 SDT270 Data Dump	
Installation Complete	
SDT270 Data Dump has been successfully installed. Click "Close" to exit. Please use Windows Update to check for any critical updates to the .NET Framewor	łk.
Cancel < Back	Close

Un nouvel écran confirme que l'application a été correctement installée. Cliquer sur "Close" pour terminer.